

Product Specifications	Ver. 1		1/4
Ultrasonic Flow Meter for Fuel Gas Management (Internal Battery Type)	Model	UW [Nominal diameter] - - [Flow direction] - [

1. Specifications

⊙ M	odel	UW [Nominal diameter] - [Pressure] BT - [F	Flow direction] - [Gas	type]
	Nominal diameter	Pressure	Flow direction	Gas type
	□ 80	□ 0 (Type without pressure sensor)	☐ L (left to right)☐ R (right to left)	☐ 13A (natural gas
	□ 100	□ 500 (Type with pressure sensor: 500kPa)	☐ R (fight to left)	12A,13A)
	□ 150	☐ 1000 (Type with pressure sensor: 1000kPa)	□ D (Downward)	☐ N2 (nitrogen)

Connection diameter

	Model	UW80	UW100	UW150
	Connection diameter	JIS10K 80A flange	JIS10K 100A flange	JIS10K 150A flange
Flow range (Actual flow) [m ³ /r				
	Model	UW80	UW100	UW150
	Flow	+3.3 to 330	+5 to 500	+12 to 1200

Accuracy

range

•	Flow measurement accuracy (Actual flow) [m³/h]				
	Model UW80		UW100	UW150	
	racy	±0.5%FS	+3.3 to 33	+5 to 50	+12 to 120
	Accu	±2.0%RD	+33 to 330	+50 to 500	+120 to 1200

- Conversion accuracy
 - ±1.5%RD (at 500 kPa or 1000 kPa, 23°C)

Conversion standard temperature : -10 to +60°C (In unit of 1°C)

Conversion standard pressure : 0.00 to 10.00 kPa (In unit of 0.01 kPa, gauge pressure)

Atmospheric pressure under operating environment : 0.0 to 200.0 kPa

(In unit of 0.1 kPa, absolute pressure)

Low flow cutoff

In case the measurement flow is lower than Qcut, 0 m²/h is displayed for instantaneous flow.

Qcut (can be changed by button operation and communication)

Model	UW80	UW100	UW150
Initial setting value	1.3	2.0	4.8

Unit: Correlated to unit of sub display value

Response-ability

Instantaneous flow display value 2 second (smoothing by moving average method

(initial setting value: 4 times))

Pressure display value 10 second (smoothing by moving average method

(initial setting value: 10 times))

Temperature display value 10 second

"⊙" are selectable items.

Reliability
Creativity Service

Product Specifications		2/4	
Ultrasonic Flow Meter for Fuel Gas Management (Internal Battery Type)	Model	UW [Nominal diameter] - - [Flow direction] - [

Display

Main display: The following is switched and selected using the "left button". Accumulated flow volume (m³)·Trip accumulated flow volume (m³)

Sub display: The following is switched and selected using the "right button".

Conversion flow type Instantaneous flow (m³/h)·Pressure (kPaG)·Temperature

(°C)

Actual flow type Instantaneous flow (m³/h) working gas pressure setting

value (kPaG)·Temperature (°C)

Number of digits displayed

Main display

Forward accumulated flow volume $[m^3]$: 0000000000 10 digits* Forward trip accumulated flow volume $[m^3]$: \vdash 000000000 9 digits*

Unit: Selected by button operation and communication

When NORMAL flow is		When standard flow is	When actual flow
	selected	selected	is selected
	NORMAL m ³	Standard m ³	m ³

*In 80A type, "Forward accumulated flow volume" and "Forward trip accumulated flow volume" are displayed with 1 decimal places when Actual flow display (m3) is selected.

Sub display

Instantaneous flow [m³/h]: 000.00 (less than 1000) 5 digits

0000.0 (1000 or more and less than 10000) 5 digits 00000 (10000 or more) 5 digits

Unit: Selected by button operation and communication

When NORMAL flow is	When standard flow is	When actual flow is
selected	selected	selected
NORMAL m ³ /h	Standard m³/h	m³/h

Pressure [kPa] : 0000.0

5 digits

Temperature [°C]: 00.0 3 digits

Contact output Nch open drain output 2 channels

• Pulse output Nch open drain output 1 channel

Pulse unit : 1000 L/P (initial setting value) (can be changed by button

operation)

(can be changed to 10, 100, 1000 and 10000 L/P)

Maximum load : 26.4 VDC·50 mA

Duty : 20 to 80%

Saturated voltage when ON : 1.5 V or less

Current when OFF : 50 µA or less

Maximum frequency: 10 Hz

^{*} In the type without pressure sensor, the working gas pressure setting value is displayed.



Product Specifications	Ver. 1		3/4
Ultrasonic Flow Meter for Fuel Gas Management (Internal Battery Type)	Model	UW [Nominal diameter] - - [Flow direction] - [

Alarm output Nch open drain output 1 channel

Battery voltage decrease alarm, flow upper or lower limit alarm, or error alarm (which one is selected by button operation)

Battery voltage decrease alarm output

When five years have passed since a battery is installed, an alarm signal is output as a battery replacement period.

Flow upper and lower limit alarm output

When the instantaneous flow becomes higher or lower than the set flow, an alarm signal is output.

(The alarm output upper and lower limit flow and alarm judgment value hysteresis width can be set by button operation.)

Error alarm output

An alarm signal is output when an abnormal flow measurement, abnormal temperature value, or abnormal pressure value is detected.

Measurable fluid Natural gas (12A,13A), nitrogen

Working fluid temperature -10 to +40°C(Natural gas),-10 to +60°C(Nitrogen)

Working pressure Type without pressure sensor : 0 to 1000 kPa (gauge pressure)

Type with pressure sensor (500 kPa) : 0 to 500 kPa (gauge pressure)
Type with pressure sensor (1000 kPa) : 0 to 1000 kPa (gauge pressure)

Working ambient temperature -10 to +60°C 90%RH or less (there must be no condensation)

Storage ambient temperature -20 to +70°C 90%RH or less (there must be no condensation)

Power supply Internal lithium battery Battery life: 5 years (at environment temperature of

20°C and humidity of 65%RH)

*A lithium battery can be replaced on-site.

Model	CR17450A
Number of pieces	Six pieces
Lithium content	0.85 g (per piece)
Туре	Assembled battery

Protection structure IP 64 (JIS C0920: dust-proof, splash-proof type) which can be installed

outdoors

Flow direction Free in upward, downward, left to right, and right to left (direction indicated

by arrow is forward flow)

Installation orientation Horizontal or vertical (cannot be installed if display part faces downward or

cable introduction part faces upward)

 Mass
 Model
 UW80
 UW100
 UW150

 Mass
 12.5 kg
 10.7 kg
 19.4 kg

	Product Specifications	Ver. 1		4/4
Ultraso for Fuel C	Ultrasonic Flow Meter for Fuel Gas Management (Internal Battery Type)	Model	UW [Nominal diameter] - - [Flow direction] - [

Material • 80A

O Measurement portion: : Engineering plastic (PPS etc.)

Outer casing : Stainless alloy

O Sensor rubber : FVMQ (Fluoro silicone rubber)

Display potion casing : Aluminum alloy *O symbol indicates the gas contacting parts.

• 100A,150A

O Measurement portion: : Stainless alloy

O Sensor holder : PPS

O Sensor rubber : FVMQ (Fluoro silicone rubber)

Display potion casing : Aluminum alloy *O symbol indicates the gas contacting parts.

Standard working period

10 years (at ambient temperature of 20°C and ambient humidity of 65%RH)

*10 years is not the warranty period.

Accessories M4 hexagonal wrench, Flange gasket(optional accessories), Bolt set(optional accessories),

Sunshade cover(optional accessories)

Others CE marking(expect 150A type), UKCA marking(expect 150A type), RoHS Directive compliant

2. Precautions in handling

2-1. Installation environment

- (1) Although the high weather-proof electronic display is adopted, in case of installation at a place subjected to direct sunlight, use a sunshade cover.
- (2) Do not install the flow meter at a place with much electromagnetic noise, in corrosive atmosphere, or with high humidity liable to cause dew condensation
- (3) This product is designed for outdoor installation, but avoid areas where there is a risk of water submergence and water always splashes.
- (4) The GND (signal ground) is connected to the casing.
 Utilize an isolated power supply or an external connection equipment, as necessary.
- (5) The meters do not conform to ATEX (explosion-proof) directive (2014/34/EU).
- (6) When opening and closing the valve installed at upstream and downstream sides of the meter, do not operate the valve at once. Open and close it slowly.

2-2. Piping conditions

- (1) There are cases that lengths of the straight pipe sections are recommended more than 20D when installing the flow meter at confluence pipe, enlarge pipe, or narrowing pipe.
- (2) Even though the meter is installed indoor, it cannot be installed with the position that the display portion faces downward or the cable introduction portion faces upward.
- (3) When installing the flow meter near a pressure reducing valve or a flow control valve, the piping conditions vary greatly depending on usage conditions. Please check the instruction manual.